EVOS™ VIPR Instructions for use.



IMPORTANT SAFETY NOTE: Whether the cylinder is in use or not, it should be restrained to avoid rotation or tipping.

Start-up



1. Remove light blue plastic cap from threaded valve Connection (B). Connect the relevant outlet hose connection (C). DO NOT OVER TIGHTEN.

Shut-off





1. To shut off the valve slowly lower the actuator lever (E) to its closed position, ensuring it engages with the safety interlock mechanism (D).





2. To open the valve, press the blue safety interlock button (D) and then slowly lift the actuator lever (E).









3. Slowly turn the flow control knob (F) in a clockwise direction to increase gas flow to the desired level (litres per minute) shown on indicator (G) at the notch. The EVOS VIPR is ready to deliver gas.



3. Disconnect the outlet hose connection (C) when the cylinder is empty or a different gas is required. The cylinder package is now safe to be stored or transported ahead of its next intended use.



